

External Wall Cladding Installation

Tools needed:

- pencil
- circular saw
- levelling tool
- tape measure
- staple gun
- heavy duty safety cutting knife
- cordless screwdriver

1

Start by measuring each panel and marking its position on the wall.

2

Use a circular saw, band saw, or drop saw with a fine tooth blade to cut the panel.

3

Once the panels are cut to your desired length, place your first panel on the wall or fence, making sure it is level.

4

Drill into the frame using black screws. We recommend using at least 18 screws per panel.

5

Place the next panel into position ensuring it interlocks.

6

Repeat this process for each panel until the wall is complete. If the last panel is too wide, trim the excess with a circular saw.